


ESSENTIAL COVER

MECHANICAL
BREAKDOWN
INSURANCE

Estimated Average Repair Costs



Can you afford NOT to be covered?

Please note: European and Executive Category Vehicles carry a much higher average than what is shown above.

ENGINE

Ancillary shaft
Balance shaft
Camshaft
Camshaft belt
Camshaft followers
Connecting rods and pins
Crankshaft
Cylinder block
Cylinder head
Cylinder head gasket
Emission control
Engine management systems
Gaskets
Hydraulic tappets
Idlers
Manifolds
Mountings
Oil filter housing
Oil pressure release valve
Oil pump
Oil pump drive gear/shaft
Oil seals
Pistons and rings
Pulleys
Pushrods and tappets
Rocker shafts
Sensors
Shell bearings and internal bushes
Timing belt or chain tensioner
Timing gears or chains or belts
Valves and guides
Valve springs

FUEL SYSTEM

Air flow meter
Fuel injection systems – sensors and wiring
Fuel gauge sender unit
Fuel pump
Fuel injection pump
Injection throttle body
Injectors
Lift pumps
Pipes

TURBO UNIT

Bearings
Boost control systems
Oil seals
Compressor wheel
Shaft
Turbine
Wastegate
Housing
Oil feed lines
Boost Sensors

ELECTRICAL

Air con computer
Air flow meter
Alternator
Central Locking
Aux power socket
Coil
Computers
Condensers
Electronic dash display
Electronic ignition
Electronic suspension systems
Engine management systems
Fuse box
Gauges – oil pressure, temperature
Heater fan motor
Horn
Indicator unit
Ignition leads
Inhibitor switch
Injection computer
Knock sensor
Pop-up headlamp motors
Pulse generators
Rear screen heater
Relays
Reverse light switch
Sensors
Speedo, rev. counter etc
Speed sensors
Stalk lights/flashers
Starter motor
Switches – including column
Throttle position sensors/switches
Transmission computer
Voltage regulator
Warning lights and sensors
Washer motors
Window regulator / electric motor
Wiper linkage's
Wiper motors
Wiring loom

COOLING SYSTEM

Engine cooling fan motor
Heating matrix
Hoses
Oil cooler
Radiator
Seals/gaskets
Thermal sensor switches
Thermostat and housing
Viscous fan
Water pump

AIR CONDITIONING

Climate control system
Cooling fan
Compressor

Condenser
Evaporator
Hoses and pipes
O Rings
Switches
Thermostat
TX valve

AUTOMATIC TRANSMISSION

Accelerator switch
Automatic drive plate
Brake bands
Casing
Clutches
Gaskets / Seals
Gears
Gear select lever
Governors
Internal bearings and bushes
Linkages
Modulator
Mountings
Oil pump
Oil seals/gaskets
Pressure control solenoids
Shafts
Temperature sensors
Torque converter
Valve block

MANUAL TRANSMISSION

Baulk rings
Casing
Extension shaft
Gears
Internal bearings and bushes
Synchro hubs
Selectors
Shafts
Gear lever
Oil seals
Linkages
Mountings
Temperature sensors
Oil seals/gaskets

CLUTCH – Manual Transmission

Clutch cable
Hydraulic pipes
Master cylinder
Slave cylinder

TRANSFER BOX – 4 WHEEL DRIVE

Bearings
Casings
Gears
Oil seals/gaskets
Selectors
Shafts

PROP SHAFT

Bearings
Couplings (including rubber mountings)
Universal joint

SUSPENSION

Anti-tramp bars
Anti-roll bar
Bushes
Coil springs
Panhand rods
Rubber mountings and bushes
Stub axle
Upper and lower wishbones
Upper and lower ball joints
Wheel bearings
Sway bar
Trailing arms
Hub assembly
Leaf springs

FRONT WHEEL DRIVE ASSEMBLY

Bearing and bushes
Constant velocity joints/Boots
Drive shafts
Hubs final drive unit
Oil seals/gaskets
Transfer gears
Transfer casing

STEERING

Ball joints
Four Wheel Steer
Idler box
Intermediate shaft
Oil seals
Power steering pump
Power steering rack & pinion
Reservoir and pressure pipes
Steering box
Steering column bushes/bearings and Universal joints
Track rod ends
Tilt steer mechanism

DIFFERENTIAL

Bearings and internal bushes
Casing
Clutches
Crown wheel and pinion
Extension shafts
Gaskets
Limited slip differential
Oil seals